

StreetPilot® c320

setup guide

START HERE

This setup guide includes instructions for loading maps to your c320 as well as configuring, mounting, and using your c320.

To ensure a successful installation, please follow the steps outlined in this guide. Do not connect the USB cable to your PC or unit until you are instructed to do so.

Before you begin . . .

Follow the setup instructions that begin below. You cannot begin using your unit until you complete all of the Setup Steps.

Setup Steps:

- Configure your c320
- Install software and map data
- Load maps

Configure Your c320

1

Press and hold the **Power** button to turn on the unit.

Note: A "Low Battery" warning may appear when you turn on the unit. In this case, charge the unit for three hours by connecting it to the enclosed AC power adapter.



2

Answer the configuration questions that appear. When you see the screen that states "To use this unit, map data must be installed," you are ready to install software and map data.



Install Software and Map Data

1

Remove the CDs from the box titled "Map Software." Insert Disk 1 into your computer.


Note: If the start-up file does not run automatically, click the Windows **Start** button and select **Run....** Type your CD-ROM's drive followed by "Setup" (for example, "E:\Setup"). Click **OK**.




2

Follow the series of instructions that appear on your computer.

When prompted, connect your c320 to your computer using the enclosed USB cable.



Where is my USB cable connection?

On your c320, note the location of the USB cable port as shown on the previous panel of this Setup Guide. On your computer, look for the USB symbol  located on the back of your computer. **Do not connect the USB cable to your unit until you are instructed to do so.**

3

Follow the instructions on your computer to register your c320.



If you do not register your c320 at this time, you can register it later by inserting Disk 1 into your computer. Check **Register your StreetPilot c320** on the screen that appears. Make certain the USB cable is connected to both your c320 and your computer.

4


When you have completed the registration process, a "Congratulations!" message appears as shown at the right. Click **Done** to load maps to your c320.



Load Maps

1

Follow the instructions given by the Map Install Wizard on your computer.




2

Select the map regions you want to load into your c320. Then click **Next**.

Use the Map Scale to zoom in and out of the map.

Click the directional arrows to move the map.

Click a map region to select it; selected map regions are shaded pink.



3

When your maps are successfully loaded, click **OK** to close the Map Install Wizard. Disconnect the USB cable from your unit. Your c320 is ready to use.

The selected map regions are listed here.

Click **Next** to load the selected map regions to your c320.


To load new maps:

Turn on your c320 and re-connect the USB cable to your unit and PC. The Map Install Wizard automatically appears.


Mount Your c320

1

Fit the bottom of your c320 into the cradle of the suction cup mount (1).




Tilt your c320 back until it snaps in place (2).



2

Place the suction cup on your windshield. Be sure the lever is flipped toward you, as shown to the right.

Note: To ensure a tight grip, make certain your windshield is clean and dry before you mount the suction cup.




WARNING: For use in vehicles, it is the sole responsibility of the owner/operator of a vehicle with the c320 installed to place and secure the device so it will not interfere with the vehicle operating controls and safety devices, obstruct the driver's view of driving conditions, or cause personal injury in the event of an accident.

NOTICE TO STATE OF CALIFORNIA DRIVERS: California Vehicle Code Section 26708 (a) (1) provides that drivers in California should not use suction mounts on their windshield or side or rear windows. Other garmin dashboard or friction mounting options should be used. For available accessories, refer to the garmin web site at www.garmin.com. Also, refer to the *Owner's Manual* for instructions on using the included mounting disk with the suction cup mount.

3

Flip the lever back, toward the windshield. Adjust the c320 to obtain a maximum viewing angle.


To remove the suction cup from the windshield, flip the lever toward you to release the suction cup's grip. To help release the grip, pull the rubber tab on the suction cup toward you.



If necessary, use the tension knob to loosen or tighten the tension in the mount to improve your viewing angle.

4

Plug the end of the cable into an available power receptacle. Your unit will turn on automatically if you have started your vehicle.



Find a Place

1

Touch **Where to?**



2

Touch an icon that will help you find your destination.



3

Touch a destination.

Pickering House Bed & E	2.3 mi NW
Kansas City Motel	2.4 mi W
Globe Corporate Stay Int	3.0 mi N
Fairfield Inn-Olathe	3.7 mi N
Residence Inn-Olathe	3.8 mi N

Back Spell ▲ ▼

4

Touch **Go!**

Residence Inn-Olathe

12215 S Strang Line Rd
Olathe, KS 66062
913-829-6700

Go!

Back Show Map Save

5

Enjoy the route!



Frequently Asked Questions

How do I contact Garmin Product Support?

In the U.S.A., call 913/397.8200 or 800/800.1020, Monday–Friday, 8 AM–5 PM Central Time; e-mail sales@garmin.com. In Europe, call 44/0870.8501241.

How do I register my c320?

If you did not register your c320 during the initial installation, insert Disk 1 and check **Register your StreetPilot c320** on the screen that appears.

How do I charge the battery in my c320?

While in your vehicle, your c320 automatically charges when the cable mount is connected to an available power receptacle.

When indoors, connect the enclosed AC power adapter to your c320. Your unit also charges when it is connected to your computer with the USB cable.

Can I use my c320 indoors?

You cannot receive GPS signals indoors, but you can use the c320 in “practice” mode when you turn off GPS. See page 20 of the Owner’s Manual for instructions.


Do I have an alternative to mounting my c320 to the windshield?

Yes. Attach the enclosed disk mount to your dashboard and place the suction cup mount on top of the disk. See page 23 of the Owner’s Manual for additional help.

Remove the Unit from the Mount


1

To remove the unit from the mount, press the indentation on the back of the unit (1).



2

Then, lift the unit off of the mount (2).



**To learn more about the exciting features that are available
with your c320, see the *Owner's Manual*.**



© Copyright 2005 Garmin Ltd. or its subsidiaries